



GUIDELINE

- Min 5' clear from blackboard
- Conduit target min 7' from blackboard (2' further than TS footprint)
- Offset to one side away from screen
- On opposite side from room entrance
- Located close to wall switches (lights, screen control)
- The TS itself is low enough that it will not obscure the view of the blackboard
- If projected image is high enough to be over instructors head than TS can be located more centrally in room if desired

TEACHING STATION LOCATION

- min. 1500mm (5') from screen wall (ideal min.)
- min. 1200mm (4') from screen wall (absolute min.)
- min. 1000mm (3'4) from side wall

- **CONDUIT FEED CENTRE LOCATION**

- Ideally located under station, towards the student side
- There is leeway in positioning TS over conduit stub
- min. 2100 (7') from screen wall (ideal min.)
- min. 1800 (6') from screen wall (absolute min.)
- min. 1500 (5') from side wall

